

# NUMMECH PRODUCTS

## T-RAIL DROP FORWARD

This drop-forward mount is intended to mimic the marker's stock bottomline mounting system. Please read these instructions before your installation.

---

### Installing the ASA onto the new drop forward:

The drop forward arrives with one set screw pre-installed inside the bottom screw holes. This set screw can only be used for a T-slot ASA adapter.

When installing your T-slot ASA, tighten the drop forward's set screw along with the pair of set screws located within the ASA itself.

The drop forward can also utilize bolt-on #10-32 ASA adapters, which will mount to any of the four bottom screw holes.

### Installing the drop forward onto your marker's grip frame:

The drop forward arrives with three set screws pre-installed in the top section, which are intended for use with a T-slot grip frame. Tighten each of the screws to mount the drop forward into position on your marker.

Optional: a pair of #10-32 threaded cap screws is included with the drop forward, which allows the drop forward to be installed onto a marker that uses bolt-on screws. The spare screws are not needed when using the grip frame that has a T-slot mount.

