

# NUMMECH PRODUCTS

## DROP FORWARD FOR BLAST / FIELD-ONE 2012+

This drop-forward mount is intended to mimic the marker's stock bottomline mounting system. Please read these instructions before your installation.

### Installation:

1. Remove your marker's grip wraps and battery (this allows access to the bottomline screws).
2. Use an allen key to loosen the stock ASA's mounting screws from within the empty grip frame. Separate the ASA from the grip frame; keep all hardware as it will be re-used with the new drop-forward.
3. Install the new drop-forward onto the marker's grip frame. Be sure an o-ring is installed within the small o-ring groove located in the upper surface of the drop-forward (see diagram below). Spare o-rings are included with the drop-forward if needed.
4. Install your tank ASA adapter onto the drop-forward. Again be sure an o-ring is installed within the small o-ring groove located on the top of the ASA (see diagram below).
5. Be sure to test out the pressure connection using your HPA tank. If you hear any leaks coming from the drop-forward's o-rings, the o-ring may have been damaged during assembly and would need to be replaced.

