

# NUMMECH PRODUCTS

## DROP BACK FOR SHOCKER RSX

This drop-back mount is intended to mimic the marker's stock bottomline mounting system. Please read these instructions before your installation.

### Installation:

1. Unscrew and remove your tank ASA adapter's knob (this allows access to the bottomline screws).
2. Use a 5/32" allen key to loosen the stock ASA's mounting screws. Loosen the front screw first, then rear screw second.  
Separate the ASA from the grip frame; keep all hardware as it will be re-used with the new drop-back.
3. Install the new drop-back onto the marker's grip frame using the two new screws included with the drop-back. Be sure an o-ring is installed within the bottom of the grip frame (see diagram below). Spare o-rings are included with the drop-back if needed.
4. Install your tank ASA adapter onto the drop-back; re-use the stock ASA screws. Tighten the rear screw first, then the front screw second.  
Again be sure an o-ring is installed within the small o-ring groove located on the underside of the drop-back (see diagram below).
5. Be sure to test out the pressure connection using your HPA tank. If you hear any leaks coming from the drop-back's o-rings, the o-ring may have been damaged during assembly and would need to be replaced.

